Mariners of Bewl Risk Assessment - Moving personnel with davit and hoist

Risk assessment and risk management record						005 MoB	
Activity	Moving personne	el with Davit and Hoist			Location	Bewl Water. MoB Pontoor	n
Identifying the hazards - assessing the risk			Risk rating				Outcome
Lifting and moving people from pontoon to boats.			All hoist operators attend a 1 day training course on installation			Low	
				procedures and use of hoist.			
				Detailed 'Method Statement' issued to all trained operators.			
Falling from ponto	on		Medium	All those involved in moving and lifting must wear			Medium
				lifejackets/ buoyancy aids before stepping on pontoon.			
				Safety belts used by wheelchair users MUST be released.			
				when on the pontoon.			
Falling from a hois	st on land or over	water	Medium	All personnel required to keep back from the edge.			Low
				Only qualified operators permitted to operate the hoist.			
				Checklist must be signed and dated on each day of use.			
				Personal Lifting Plans to be followed.			
				Minimum of 2 people required to manage a lift/transfer.			
				Dinghies to be moved into correct position ready to			
				receive the sailor before a lift commences.			
				Personnel being lifted must never be left unattended or left			
				hanging over water, dinghy pontoon or wheelchair.			
				Wheelchairs or seating to be removed from pontoon			
				once lift is completed.			
Condition of sling			Medium	Checked as per LOLER Regulations 1998. Visual check			Low
				carried out prior to every use.			
				If personal slings are to be used written certification			
				that sling is in date and compatible is required before use.			
Incorrect fitting of sling to person		Medium	Correct size of slings used and Personal Lifting Plan followed.			Low	
				Ensure that hoist is correctly positioned to prevent the body of			
				hoist hitting the face of person being lifted.			
Slipping out of sling				Slings fitted according to manufacturers recommendation and			
				as shown/practiced on training course.			
Incorrect attachme	ent of sling to hois	t	Medium	All hoist operators trained in attaching slings to hoist.			Low
				Users and/or carers/P.A's to assist 'hoist operator' by			
				checking that slings are correctly attached.			
Weight limit of sai	lor exceeding state	ed limits of equipment	High	Trained operators ensure compliance with weight limits of			Low
J.g.n. min. Ji bai	choocanig olar	Su	9	hoist, sling and craft.			
				noist, siing and orait.			
Completed:	Date	25/03/2024		Review date	: March 202	25	
p	20.0	01 6		Troviow date		-	
Signature:	Club Officer			Seen/read by Chai	r:		
Please Print name		ard Hayden RYA Senioi	Instructor and Da				